

## STANDARD RECEIVERS



1

<u>Item #</u>	<u>Item Name</u>	<u>Fluid</u>	<u>Thread Size</u>	<u>Overall Length</u>	<u>Threads per Inch</u>
<a href="#"><u>971-0985-01RC</u></a>	Receiver & Cover	Coolant	1/2 in	2.02 in	14
<a href="#"><u>971-0985-01R</u></a>	Receiver	Coolant	1/2 in	2.02 in	14
<a href="#"><u>971-0985-01C</u></a>	Cover	Coolant	N/A	N/A	N/A
<a href="#"><u>971-0986-01RC</u></a>	Receiver & Cover	Hydraulic	1/2 in	1.94 in	14
<a href="#"><u>971-0986-01R</u></a>	Receiver	Hydraulic	1/2 in	1.94 in	14
<a href="#"><u>971-0986-01C</u></a>	Cover	Hydraulic	N/A	N/A	N/A
<a href="#"><u>971-0987-01RC</u></a>	Receiver & Cover	Transmission	3/4 in	2.74 in	14
<a href="#"><u>971-0987-01R</u></a>	Receiver	Transmission	3/4 in	2.74 in	14
<a href="#"><u>971-0987-01C</u></a>	Cover	Transmission	N/A	N/A	N/A

<u>Item #</u>	<u>Item Name</u>	<u>Fluid</u>	<u>Thread Size</u>	<u>Overall Length</u>	<u>Threads per Inch</u>
<u>971-0988-01RC</u>	Receiver & Cover	Crankcase	3/4 in	2.57 in 65.2 mm	14
<u>971-0988-01R</u>	Receiver	Crankcase	3/4 in	2.57 in 65.2 mm	14
<u>971-0988-01C</u>	Cover	Crankcase	N/A	N/A	N/A